



Cardinal Architectural

Caring For And Using Your Motorized Pergola!

Thank you for your purchase of your new louvered roof. It is designed to give you years of use. These instructions are designed to help you operate, maintain, and care for the product.

Cautions:

1. Never allow louvers be kept from opening or closing all the way with foreign objects. The motor is very powerful and damage to the mechanism or louvers can occur if they are not allowed to make their full range of motion.
2. Never operate the mechanism when snow or ice are present for the same reason.
3. Open the louvers completely and clean off with a garden hose when needed. You can also use a soft bristle brush and mild soap. Make sure you rinse them completely.
4. You may want to unplug the control box(s) during the freezing months to prevent the louvers from opening or closing.

Operating the remote control

If you have a single motor your remote control will work when it is on the first channel or light. To change channels use the left or right arrows to get to channel 1 or the first light. If you have more than 1 motor – each motor will have a light.

To open the louvers use the up arrow (you do not need to hold the buttons down louvers will automatically stop when they are at the end of the cycle open or closed) to close the louvers use the down arrow.

To stop the louvers push the middle button at any time.